



GRILL BURNER ASSEMBLY

ITEM	DESCRIPTION	PART NO.
1	GRILL RACK S/S 26	19498
2	RADIANT	33094
3	26" HEAT SHIELD, SIDE R/H	33096-01
	26" HEAT SHIELD, SIDE L/H	33096-02
4A	SS GRILL BURNER	12291
4B	AIR SHUTTER	12003-1
5	26" HEAT SHIELD, CENTER	33095
6	MANIFOLD 26	18469

ITEM	DESCRIPTION	PART NO.
7	CONTROL VALVE	13017
8	CONTROL KNOB	14351
9	KNOB BEZEL	14006-PL
10	COLLECTOR BOX	32801
11	NI-CHROME WIRE COIL	32313
12	BURNER ELECTRODE L/H	16281-02
	BURNER ELECTRODE R/H	16281-03
13	SCREW	15001-23
14	BRACKET, IGNITION MODULE, ELTEC4	30991
15	IGNITION MODULE 2 OUTPUTS (BQ MOD)	18349
16	BEZEL SCREW	15001-29
17	IGNITION BUTTON	18353
18	MANIFOLD BOLT	15003-15
19	REGULATOR (LP GAS)	13230
20	REGULATOR (NAT. GAS)	13035
21	ALKALINE 9V BATTERY	18354



GRILL BODY PARTS LIST



ITEM	DESCRIPTION	PART NO.
1	FOLDING LID W/A BGA26	33054
2	HANDLE END CAP	18372-01/02
3	SHOULDER BOLT	15003-06
4	HANDLE TUBE	32048-09
5	WARMING RACK BGA26	19497
6	BODY ASSEMBLY 26	33097
7	BOLT (SMALL)	15002-36
8	WARMING RACK RET. 26 L/H	32340-01
	WARMING RACK RET. 26 R/H	32340-02
9	LANDING LEDGE W/ASSY. 26	33129
10	CAGE NUT	15073
11	VALVE PANEL BGA26-BQN	33084-PA
	VALVE PANEL BGA26-BQL	33084-PA
12	DCS LOGO	17382-01
13	TORX SCREW	15002-41
14	MATCH LITE, CLIP	32563
15	DRIP PAN 26 W/A	33127
16	REAR SERVICE PANEL	33077
17	LOWER SERVICE PANEL	3309

GRILL CART PARTS LIST

ITEM	DESCRIPTION	PART NO.
1	SIDE SHELF ASSY	33058
2	WASHER	15005-15
3	BOLT	15003-06
4	FRONT PANEL W/A	33093
5	SIDE PANEL L/H	33088-02
6	BACK BRACE	33090
7	CASTER STIFFENER	33092
8	CASTER W/BRAKE	18027
	CASTER W/O BRAKE	18027-01
9	SCREW	15002-29
10	SCREW	15003-06
11	NUT	15021-04
12	NUT	15021-09
13	CASTER FIXED W/O BRAKE	18448
14	SIDE PANEL R/H	33088-01
15	BOTTOM PANEL	33087

